

* Notes:

- Vertical battens and horizontal packers to be secured by 30 mm clout or adhesive against building underlay. These may be H3.1 timber or extruded or H.D. Polystyrene, with a nominal profile of 20 mm x 50 mm.
- Horizontal packers tilted to 5°.
- Refer Wall Batten Layout Around Windows for batten layout around joinery.
- Building underlay & bottom cavity cap not shown for clarity.
- Vertical battens can be used between studs as an alternative to strapping.

© 2019 Petros Holdings Ltd



MPT Petrapanel

Wall - Framing Layout Timber Framing With Battens Date: January 2020 Scale: 1:20 @ A4 AAC 50 or 75 mm Panel Revision: 2

Reference: A C002