



Notes:

- Vertical timber battens & horizontal packers to be secured by 30mm clouts against building underlay.
- Horizontal packers can either be set level if vented & bevelled, or tilted to 5° if solid.
- Nailing: Use 60 x 3.15mm fibre cement nails, nails at 200mm centres on studs, nails at 150mm centres on top plate and bottom plate. Nails must be driven a minimum of 12mm from the sheet edges and 75mm minimum from corners and must finish flush with sheet surface.
- Special fixing arrangements are required for bracing systems – refer to sheet manufacturer.

© 2019 Petros Holdings Ltd



Mineral Plaster
Technology

61 Hillside Rd, Wairau Valley
Auckland 0627
New Zealand
www.mineralplaster.co.nz Ph: 0800 25 23 678

MPT Liteclad
Liteclad System

Reference: mpt_I001
Date: January 2020
Scale: 1 : 2 @ A4
Revision: 2

TERMS OF USE Disclaimer: This information is intended solely as a guide for use of MPT products. Before using you should ensure that the product is suitable for use in the specific application. Nothing in this information constitutes a statement of fitness for particular purpose and appropriate expert advice is to always be obtained. Petros Holdings Ltd makes no warranty regarding the use of this information. This drawing is the property of Petros Holdings Ltd. It must not be copied in any form except for the purpose of specifying the use of MPT products in construction projects.