



* Notes:

- Vertical H3.1 timber battens and horizontal packers to be secured by 30 mm clouts against building underlay.
- Horizontal packers tilted to 5°.
- Refer Wall - Batten Layout Around Windows for batten layout around joinery.
- Building underlay & bottom cavity cap not shown for clarity.
- Vertical battens can be used between studs as an alternative to strapping.

© 2019 Petros Holdings Ltd



61 Hillside Rd, Wairau Valley
Auckland 0627
New Zealand
www.mineralplaster.co.nz Ph: 0800 25 23 678

MPT Liteclad System

Wall -Framing Layout Timber Framing with Battens

Reference: mpt_I082

Date: January 2020

Scale: 1 : 20 @ A4

Revision: 2