



* Notes:

- Vertical battens and horizontal packers to be secured by 30 mm clout or adhesive against building underlay. These may be H3.1 timber or extruded or H.D. Polystyrene, with a nominal profile of 20 mm x 50 mm.
- Horizontal packers tilted to 5°.
- Refer Wall - Batten Layout Around Windows for batten layout around joinery.
- Building underlay & bottom cavity cap not shown for clarity.
- Vertical battens can be used between studs as an alternative to strapping.

© 2019 Petros Holdings Ltd



61 Hillside Rd, Wairau Valley
Auckland 0627
New Zealand
www.mineralplaster.co.nz Ph: 0800 25 23 678

MPT Petrapanel
Wall - Framing Layout Timber Framing With Battens

AAC 50 or 75 mm Panel

Reference: A_C002

Date: June 2021

Scale: 1 : 20 @ A4

Revision: 2