

Notes:

- Horizontal packers must be set to a fall of 5° min.
- Refer to NZBC E2/AS1 Table 7 for flashing cover dimensions.

© 2019 Petros Holdings Ltd

