



Notes:

- Ensure batten layout is in accordance with board manufacturers specifications.
- Additional battens may be required at window framing, avoid battens under jambs.
- Horizontal spacers at framing noggs centres 100mm max - length set at 5 degrees.
- Timber battens to be H3.1 treated as per NZS 3602.
- Air flow to be blocked at soffits to prevent cross or through ventilation.
- Gables to be lined or have an air barrier wrap installed.

© 2019 Petros Holdings Ltd

Mineral Plaster
Technology

61 Hillside Rd, Wairau Valley
Auckland 0627
New Zealand
www.mineralplaster.co.nz Ph: 0800 25 23 678

MPT Fibreclad System
Wall - Framing Layout Timber Framing With Battens 400

Reference: MPT_F081
Date: June 2019
Scale: 1 : 20 @ A4
Revision: 2