



**Notes:**

- Fixings through top of parapet are not permitted.
- Ensure parapet is temporarily waterproofed prior to plastering.
- Install metal saddle flashing at wall junction.
- Install metal capping to all roof parapets.
- Metal cap excluding dripedge must overlap board by 100mm minimum.
- Refer to NZBC E2/AS1 Table 7 for flashing cover dimensions.

© 2019 Petros Holdings Ltd

 <p>61 Hillside Rd, Wairau Valley Auckland 0627 New Zealand www.mineralplaster.co.nz Ph: 0800 25 23 678</p>	<p><b>MPT Fibreclad System</b> Parapet - Flat</p>	Reference: MPT_F053
		Date: September 2020
		Scale: 1 : 2 @ A4
		Revision: 3

TERMS OF USE Disclaimer: This information is intended solely as a guide for use of MPT products. Before using you should ensure that the product is suitable for use in the specific application. Nothing in this information constitutes a statement of fitness for particular purpose and appropriate expert advice is to always be obtained. Petros Holdings Ltd makes no warranty regarding the use of this information. This drawing is the property of Petros Holdings Ltd. It must not be copied in any form except for the purpose of specifying the use of MPT products in construction projects.